



Ready... Set...  
**Install!**

**Breezeline Stream TV**

# Thanks for choosing Breezeline

In this guide, we'll walk you through how to set up your new Breezeline Stream TV. We look forward to introducing you to a whole new world of streaming excellence.

We hope you enjoy your new Breezeline Stream TV.

## What's inside?

Introducing Breezeline Stream TV .....	<b>3</b>
What you'll need .....	<b>4</b>
Installing your new Breezeline Stream TV Box .....	<b>6</b>
Stream TV Remote essentials .....	<b>10</b>
Getting started with Breezeline Stream TV .....	<b>12</b>

Don't feel like reading?

▶ [Click Here to Watch Our Installation Video](#)

Or visit: [breezeline.com/streamtvinstall](https://breezeline.com/streamtvinstall)

# Welcome to the next-generation video streaming experience!

With **Breezeline Stream TV**, you can have total control of your entertainment experience by connecting your Stream TV box or mobile device to your WiFi internet.

## BREEZELINE STREAM TV WILL ALLOW YOU TO

- Never miss a show with advanced time-shifting features such as Live Rewind, Start Over and Catch Up.
- Search across live TV, DVR recordings, On Demand, and streaming apps like Netflix, Amazon Prime, Disney+, and more to easily find and watch what you're looking for, all by using voice commands with Google Assistant or using the Search feature.
- Watch TV anytime or anywhere on your iOS or Android mobile device—at home or on the go. Stream TV is also available for Apple TV and Fire TV devices in your home.




## What's inside

The following instructions will take you through all the steps necessary to get your Breezeline Stream TV up and running.

### WHAT YOU'LL NEED



Your Breezeline Stream TV Box




Power Cord



Remote Control



Batteries (included)



HDMI Cable

Level of Difficulty:



Easy

Time to Complete:



15 Min


Required Steps:



5 Easy Steps


# Connecting your Breezeline Stream TV

1. Connect one end of the HDMI cable to the Breezeline Stream TV device and the other into your TV.
2. Attach the power adapter to the Breezeline Stream TV and plug it into the closest electrical outlet.






# Setting up your new Breezeline Stream TV Box

Take these important steps to make sure you get the most out of your Breezeline Stream TV:

1. Follow the on-screen instructions using your remote to navigate the set up process:
  - o Pair the remote by pressing the  button. (The light on the Stream TV Box will flash amber while pairing.)
  - o Choose your preferred language.
  - o Connect to your WiFi Network\*\*
  - o Sign-in to Google to make the most of your Stream TV experience — this is optional, but recommended. Answer the account-related questions.
  - o Choose a name for your new Stream TV Box.
  - o Install additional apps from the Google Play Store (optional).
  - o Pair the Stream TV remote to your TV. You will also have the option to connect the Stream TV remote with your Audio Device, such as a sound bar.

\*\*If you have an Android phone, you can easily transfer your phone's WiFi network and Google account to your Stream TV Box. (This is not supported on an iPhone.)



**Please Note:** You will need to sign-in or create a Google account to use the Google Assistant voice commands and to download your favorite streaming apps from the Google Play Store.

**2. Wait for any software or security updates:** After successfully connecting to WiFi, your Stream TV Box will check for updates and, if available, download and install them, and then the box will reboot. Set up will resume after the reboot is complete.

**3. Pre-select OnePass options (Optional):**

- The OnePass Quick Select screen allows you to choose popular TV shows you may want to record.
- The Streaming Apps screen allows you to select the apps that you want to be connected to your OnePass shows.

That's it! Now you're ready to enjoy the next generation of video entertainment. Watch your favorite channels, and stream your favorite apps all from your Stream TV Box.





**Please Note:** If your Breezeline Stream TV Box won't start the install process or if it finishes the install process and live video doesn't start playing, try unplugging the power cord from the Stream TV Box, wait 60 seconds, and then plug the power cord back in. If that does not resolve the issue go to [breezeline.com/support/tv/streamtv](https://breezeline.com/support/tv/streamtv) for additional information or contact customer service at 1.888.536.9600.

## Installation Pro tips



### Tip

- If for any reason your Stream TV Remote stops controlling your Stream TV Box, press the  and  buttons simultaneously until the indicator light on the remote turns red.
- Using the HDMI cable, your Stream TV Box can be connected to other devices like a monitor, secondary display, or even a projector you can use for home movie night.
- Your Stream TV Box has Chromecast built-in, so you can quickly cast photos, videos, and music from your smart phone right to your TV.
- Each Stream TV Box in your home can have the same or a different Google Account on it and different apps from the Google Play Store can be downloaded on each box.



# Download the Breezeline Stream TV App

Go to the Apple App Store, Google Play Store, or Amazon App Store on your mobile phone, tablet, Apple TV, or Fire TV device. Search for the “Breezeline Stream TV” App and download it.



**Breezeline  
Stream TV App**




**Please Note:** A Stream TV Box must be installed in your home before the Stream TV app will work on another device. Some video programming content is unavailable for viewing outside of your service address location. Available content varies by region.

# Stream TV Remote Essentials

The Fast Forward, Rewind, and Pause/Play functions will appear on your TV screen. Use the middle buttons (OK/Select, LEFT, RIGHT) on your remote control to operate those on-screen functions while watching video.

## QUICK TIPS


- Push the **Exit** button while watching Live TV to go to the Last Channel you viewed.
- Push the **i** button while watching Live TV to Record the show you are watching (Cloud DVR service required).





- A** POWER turns the television on/off.
- B** GUIDE takes you to the program guide.
- C** VOL and MUTE control the TV audio.
- D** While navigating the TiVo menus:
  - Use UP, DOWN, LEFT, or RIGHT to move around the screen.
  - The center button (OK/Select) chooses menu items.
  - While watching video:
    - DOWN displays the Info banner.
    - UP opens the mini guide.
    - OK/SELECT brings up Trick Play controls. With Trick Play controls visible:
      - DOWN opens the Continue Watching and Favorite Channels panels.
- E** BACK starts full-screen video on the Home screen, and goes back to the previous screen on other menus.
- F** Press and release the Google Assistant button to talk to Google.
- G** VOD goes directly to the On Demand library.
- H** The NETFLIX button launches Netflix.
- I** INPUT changes your video source (TiVo device, gaming, etc).
- J** CH UP/DOWN changes the channel or moves you quickly through lists and the guide.
- K** The TiVo button takes you to the Home Screen.
- L** INFO ( **i** ) brings up the full Info banner while watching a show with options to Record, Bookmark, Change Audio Track, etc.
- M** EXIT switches to full-screen video while using TiVo menus, or jumps back to the LAST CHANNEL viewed while watching live TV. Exit also exits a Start Over/Catch Up show.
- N** The grid button jumps to the Apps & Games screen.
- O** The NUMBER BUTTONS make it easy to enter numbers (e.g., channel numbers or Parental Controls PIN).



## Getting started with Breezeline Stream TV

**Home Screen:** The Home screen is the starting point for just about everything you do with your Breezeline Stream TV.


To get to the Home screen, just press the  button on your remote control.

**Google Assistant:** Press and release the  button on your remote, and use your voice to find a show, open an app, or get recommendations to match your mood. Try saying things like “Play Bob’s Burgers,” “Find romantic movies,” or “Show me basketball games.”



**Apps & Games:** You can access all the apps, games, and music available from the Google Play store. Just select Apps & Games from the Home screen or click the grid button  on your remote to instantly jump to the Apps & Games screen.




**Live Rewind:** Tune to any TV channel at any time and rewind or pause Live TV up to 60 minutes using the on-screen buttons (no DVR service required!).



**My Shows:** All of your recordings and streaming videos will appear in My Shows. To get to My Shows from any menu screen or from live TV, just press the  button to go to the Home screen, then choose My Shows.


**What to Watch:** So many channels, so little time! TiVo's What to Watch lets you browse shows available to stream, watch live, bookmark, or record. From the Home screen, select What to Watch.



## Getting started with Breezeline Stream TV



**Start Over & Catch Up:** Look for the icon  for shows available from Start Over or Catch Up.


- Start Over:** Choose an in-progress show with the  icon from the Guide or mini guide. Start watching, then press and hold OK to start over from the beginning.
- Catch Up:** If you missed an episode when it aired, Catch Up lets you watch it after the fact for up to 72 hours even if you haven't recorded it. To find Catch Up shows, move LEFT in the Guide to a previous day. Select a show with the  icon, and choose Watch now from Catch Up.




**Favorite Channels:** To add a channel to your Favorites go to the Guide, highlight a channel name/number (not a show/program), press **OK/SELECT**, and then choose Add to Favorite Channels.

To jump to one of your favorite channels while watching TV, press **OK/SELECT** to bring up the Trick Play controls, then press **DOWN** to view the Continue Watching panel. Press **DOWN** a second time to bring up your Favorite Channels.


**Menu & Notifications:** To manage your recordings and OnePass searches, control your settings, and get help, select  Menu. Here, you'll be able to customize your options, including OnePass settings, Parental Controls settings and User Preferences. To view notifications, move left to select the envelope icon .

**Parental Controls:** Parental Controls help you make sure your family has access to only those shows you want them to watch. From the Home screen, select  Menu > Settings > Parental Controls.

- **To Turn Parental Controls On:** Enter a four-digit PIN, then enter the same PIN again for confirmation. When Parental Controls are on, a lock icon will appear on the Home screen next to the Menu icon .
- **To Turn Parental Controls Off:** When you turn off Parental Controls, the PIN is deleted and anyone can watch any show or channel.

**Subtitles & Closed Captioning:** Turn subtitles or closed captioning on for all shows. To turn subtitles or closed captioning on or off while watching a show, press  on your remote to open the Info banner, and then select Turn Closed Captions On/Off.

## SETTINGS MENU





## Need additional support?

Check out the how-to videos for Breezeline Stream TV

▶ [Click Here to Watch  
Our how-to Videos](#)

You can also visit [breezeline.com/support/tv/streamtv](https://breezeline.com/support/tv/streamtv) to check out additional online resources.

STREAMTV\_0223